

TENT SEATING CAPACITY CHART

	SQUARE FOOTAGE	CATHEDRAL SEATING, STAND-UP COCKTAIL	BUFFET DINNER	SIT DOWN DINNER
--	----------------	--------------------------------------	---------------	-----------------

POLE TENTS- Example: Anchor Original Party® Tent, Party® Mate, Century® Mate

16'x16' Sq. End	256	42-52	32-36	26
20'x20' Sq. End	400	60-70	50-58	40
20'x40' Sq. End	800	130-160	100-115	80
10' Mid for 20' Tent	200	34-40	25-30	20
30'x30' Sq. End	900	150-180	112-130	90
30'x45' Sq. End	1350	225-270	170-190	135
30'x60' Sq. End	1800	300-360	225-258	180
15' Mid for 30' Tent	450	75-90	65-75	45
30' Mid for 30' Tent	900	150-180	112-130	90
40'x40' Sq. End	1600	267-320	200-230	160
40'x60' Sq. End	2400	400-480	300-344	240
40'x80' Sq. End	3200	534-640	400-458	320
20' Mid for 40' Tent	800	133-160	100-114	80
60'x60' Sq. End	3600	600-720	450-514	360
60'x90' Sq. End	5400	900-1080	675-772	540
30' Mid for 60' Tent	1800	300-360	225-258	180
80'x80' Sq. End	6400	1067-1280	800-915	640
80'x100' Sq. End	8000	1334-1600	1000-1143	800
100'x100' Sq. End	10000	1667-2000	1250-1429	1000
20' Mid for 80' Tent	1600	267-320	200-230	160
30' Mid for 80' Tent	2400	400-480	300-344	240
30' Mid for 100' Tent	3000	500-600	375-429	300

FRAME TENTS- Example: Anchor Fiesta® Frame Tents, Navi-Trac®, Century® Frame Tents

16'x16' Sq. End	256	42-52	32-36	26
20'x20' Sq. End	400	60-70	50-58	40
20'x40' Sq. End	800	130-160	100-115	80
10' Mid for 20' Tent	200	34-40	25-30	20
30'x30' Sq. End	900	150-180	112-130	90
30'x45' Sq. End	1350	225-270	170-190	135
30'x60' Sq. End	1800	300-360	225-258	180
15' Mid for 30' Tent	450	75-90	65-75	45
30' Mid for 30' Tent	900	150-180	112-130	90
40'x40' Sq. End	1600	267-320	200-230	160
40'x60' Sq. End	2400	400-480	300-344	240
40'x80' Sq. End	3200	534-640	400-458	320
20' Mid for 40' Tent	800	133-160	100-114	80
40'x40' Sq. End	1600	267-320	200-230	160
40'x60' Sq. End	2400	400-480	300-344	240
40'x80' Sq. End	3200	534-640	400-458	320
20' Mid for 40' Tent	800	133-160	100-114	80
40'x40' Center	1600	267-320	200-230	178

TENSION TENTS- Example: Anchor New Century® Tents

60'x40' Sq. End	2400	400-480	300-344	267
60'x70' Sq. End	4200	700-840	525-600	467
60'x100' Sq. End	6000	1000-1200	750-858	67
30' Mid for 60' Tent	1800	300-360	225-258	200
60'x40' Center	2400	400-480	300-344	267
80'x40' Sq. End	3200	534-640	400-458	356
80'x70' Sq. End	5600	934-1120	700-800	623
80'x100' Sq. End	8000	1334-1600	1000-1143	889
30' Mid for 80' Tent	2400	400-480	300-344	267